



Susol & **Metasol**
Super Solution *Meta Solution*

Air Circuit Breakers

**Digital Trip Relay(P.S Type)
Manual**

LS IS
www.lsis.com

Susol & Metasol ACB

Digital Trip Relay Manual

A. P/S Type Relay Setting

1. Fine Adjustment of Relay Setting Current – OCR	3
2. Fine Adjustment of Relay Setting Current – OCGR	5
3. Over Voltage/Under Voltage Relay (OVR / UVR)	6
4. Voltage/Current Unbalance Relay (Vunbal / Iunbal)	8
5. Reverse/Over Power	10
6. Over/Under Frequency Relay (OFR, UFR)	12

B. P/S Type Measurement Display

1. Measurement Display Arrangement	14
2. Initial Display and Measurement Outline	15
3. Vector Diagram Display	16
4. Power Diagram Display	17
5. Energy Measurement Display	17
6. Waveform and Harmonic Analysis Display	18

C. P/S Type Device Setting

1. Menu Arrangement	19
2. Device H/W Setting – Wiring Setting	20
3. Device H/W Setting – Communication Setting	21
4. Device H/W Setting – Password Setting	22
5. Device H/W Setting – Time Setting	23
6. Device H/W Setting – PT Ratio Setting	24
7. Device H/W Setting – Demand Setting	25
8. Device H/W Setting – Data Reset	26
9. Device H/W Setting – DO Setting	27
10. Device H/W Setting – Language Setting	29
11. Event Information Display	30
12. Fault Information Display	33
13. Event/Fault information Deletion	35
14. System Information Display	36
15. Local/Remote Setting	37



Safety Precaution



WARNING

1. Please do not operate, inspect, and install by yourself.
2. Please do not wiring operation during power-on or under operation; it may result in electric shock.
3. Please do not wiring operation with the live bus bar; it may result in electric shock or a fire and property damage by charging voltage of current transformer.
4. Please do not attempt to disassemble even when the power not applied; it may result in electric shock by charging current remained in the product.
5. Please do not wire or operate with wet hands; it may result in electric shock.
6. Please do not use any damaged cable; it may result in electric shock.
7. Please work after wearing safety gear.
8. Please work after setting up the safety caution sign.
9. Please disconnect all Input/output wires when measuring HI POT or meger.



CAUTION

- Safety caution for installation & terminal wiring
 1. Apply the rated voltage to the power supply terminal; it may result in property damage or fire.
 2. Please keep away product from screws, metals, water, or oil; it may result in fire.
 3. Please keep the rated load and polarity of input & output contacts; it may result in property damage or fire.
 4. Specialist help shall be sought for the installation and maintenance of product; it may result in malfunction or accident.
- Inspection item before power supply being applied
 1. Check the voltage or polarity of control power supply.
 2. Check the wiring condition of input/output terminal.
- Caution for storage and handling
 1. Please store at dry and clean place.
 2. Please do not throw or put force on it during transport.
It may result in malfunction or faulty operation.
- Caution for disposal
 1. Please dispose of it in accordance with industrial waste regulation.

A. P/S Type Relay Setting


1. Fine Adjustment of Relay Setting Current - OCR

CAUTION


- OCR and OCGR's relay setting operate basically from Knob's setting values.
- Knob's adjusting measure is determined by its scale unit.
- In case of using current value that can not be precisely adjusted from its scale, it is recommended to use fine adjustment function.

Necessity for Fine Adjustment


Measurement Display




Configuration



Password Input



Relay Setting Display



Fine Adjustment Display

CAUTION

- When passwords has not been entered, move its cursor to the far right, then press Enter key will process to next page. Once the password was created, following above direction will not work to pass through this screen.



A. P/S Type Relay Setting


1. Fine Adjustment of Relay Setting Current - OCR




CAUTION

- Fine adjustment is only feasible in-between setting range of knob scale.
- During its fine adjustment process, any changes in Knob from users will reset all of pre-adjusted microscopic data.
- OCR and OCGR are managed separately. So adjusting OCR's Knob (Long, Short, Instantaneous) will not make a change in OCGR's fine adjustments

Fine Adjustment Range





Long time delay setting knob is currently positioned at 0.8.
 If I_n is equaled to 1000A.....
 Fine adjustment range is $0.8 \times I_n \sim 0.9 \times I_n - 1$.
 Thus, fine adjustment can be taken place from 800A~ to 899A.



Display	Button	Contents
Fine Adjustment 		1) Move the cursor by pressing the ▼▲ button 2) If you press Enter button, the cursor blink
		Upper level menu after saving data
		Upper level menu without saving
Enter-YES Esc-NO		

A. P/S Type Relay Setting

1. Fine Adjustment of Relay Setting Current - OCGR





A. P/S Type Relay Setting

2. Over Voltage / Under Voltage Relay (OVR / UVR)



CAUTION

- When over/under voltage take place in any phase of 3 phase voltage, TRIP/None/DO1/DO2/DO3/Fault will be executed.
- Under voltage relay operates where maximum voltage is above 60V among 3 phase. If all voltages from 3 phase are below 60V, Under voltage relay becomes disable.
- Each phase will be applied independently by over voltage / Under voltage relay. If all of 3 phase voltages are experiencing low voltage at once, it will record all of 3 fault events.



A. P/S Type Relay Setting

2. Over Voltage / Under Voltage Relay (OVR / UVR)


Relay Operation-Action Setting

- There are 6 kinds of action in relay operation.

1. None: Relay function was not implemented.
2. Fault: Under OVR, UVR operating condition, it records fault events only.
3. DO1: Under OVR, UVR operating condition, it records fault events, and close D01 relay.
4. DO2: Under OVR, UVR operating condition, it records fault events, and close D02 relay.
5. DO3: Under OVR, UVR operating condition, it records fault events, and close D03 relay.
6. Trip: Under OVR, UVR operating condition, it records fault events and trip ACB, but does not close DO relay(s).

Relay Setting Range

1. OVR Pick-up: UVR Pickup setting value ~ 900V
2. UVR Pick-up: 80V ~ OVR Pickup setting value -1V
3. Delay: 1.2S ~ 40S




A. P/S Type Relay Setting

3. Voltage / Current Unbalance Relay (Vunbal / Iunbal)

Relay Operation-Action Setting

- There are 6 kinds of action in relay operation.
- 1. None: Relay function was not implemented.
- 2. Fault: Under Vunbal/Iunbal operation condition, it records fault events only.
- 3. DO1: Under Vunbal/Iunbal operation condition, it records fault events, and close D01 relay.
- 4. DO2: Under Vunbal/Iunbal operation condition, it records fault events, and close D02 relay.
- 5. DO3: Under Vunbal/Iunbal operation condition, it records fault events, and close D03 relay.
- 6. Trip: Under Vunbal/Iunbal operating condition, it records fault events, trip ACB, but does not close DO relay(s).




D. P/S Type Relay Setting

4. Reverse/Over Power Relay

⚠ CAUTION

- When total active power of 3 phases overflow more than its setting in reverse direction, Trip / None / DO1 / DO2 / DO3 / Fault function can be prearranged.
- Pickup Setting: Reverse Power->10~500kW(Step: 1kW) , Over Power-> 500~5000kW(Step: 1kW)
- Relay is valid between 0 ~ 60 degree of absolute phase angle (voltage-current phase difference)

Measurement Display



Configuration

M

1.H/W Set
2.Relay Set
3.Events
4.Sys Info
5.L/R (L)

1.H/W Set
2.Relay Set
3.Events
4.Sys Info
5.L/R (L)

Password Input

1.OCR
2.OCGR
3.OVR/UVR
4.Unbal
5.rP/OPR

1.OCR
2.OCGR
3.OVR/UVR
4.Unbal
5.rP/OPR

Relay Setting Screen

rP/OPR

Pick Up : 100 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

Reverse Power Setting

rP/OPR

Pick Up : 100 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

rP/OPR

Pick Up : 100 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

rP/OPR

Pick Up : 200 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

SETTING CHANGE ?
Enter-YES
Esc-NO

rP/OPR

Pick Up : 200 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

rP/OPR

Pick Up : 100 kW
Delay : 15.0 s
Action : None
Pick Up : 2150 kW
Delay : 10.0 s
Action : D03

1.OCR
2.OCGR
3.OVR/UVR
4.Unbal
5.rP/OPR

← Upper level menu after saving data

Reset ESC Upper level menu without saving


A. P/S Type Relay Setting

4. Reverse / Over Power

Relay Operation-Action Setting

- There are 6 kinds of action in relay operation.

1. None: Relay function was not implemented.
2. Fault: Under rP, OPR operation condition, it records fault events only.
3. DO1: Under rP, OPR operation condition, it records fault events, and close D01 relay.
4. DO2: Under rP, OPR operation condition, it records fault events, and close D02 relay.
5. DO3: Under rP, OPR operation condition, it records fault events, and close D03 relay.
6. Trip: Under rP, OPR operating condition, it records fault events, trip ACB, but does not close DO relay(s).





A. P/S Type Relay Setting

5. Over / Under Frequency Relay (OFR, UFR)



CAUTION

- When frequency on R phase voltage is greater than its setting value, Off/Alarm/DO function can be prearranged.
- Pickup Setting:
 - Over Frequency (60Hz) : Under Frequency Pickup Value ~ 65Hz (Step: 1Hz)
 - (50Hz) : Under Frequency Pickup Value ~ 55Hz
 - Under Frequency (60Hz) : 55Hz ~ Over Frequency Pickup Value
 - (50Hz) : 45Hz ~ Over Frequency Pickup Value
- Relay Voltage Range : R phase voltage above 80V ~ below 900V




A. P/S Type Relay Setting

5. Over / Under Frequency Relay (OFR, UFR)

Relay Operation-Action Setting


- There are 6 kinds of action in relay operation.

1. None: Relay function was not implemented.
2. Fault: Under OFR, UFR operation condition, it records fault events only.
3. DO1: Under OFR, UFR operation condition, it records fault events, and close D01 relay.
4. DO2: Under OFR, UFR operation condition, it records fault events, and close D02 relay.
5. DO3: Under OFR, UFR operation condition, it records fault events, and close D03 relay.
6. Trip: Under OFR, UFR operating condition, it records fault events, trip ACB, but does not close DO relay(s).



B. P/S Type Measurement Display

1. Measurement Display Arrangement



E. P/S Type Measurement Display

2. Initial Display and Measurement Outline



CAUTION

- If there is no key input for 3 minutes at least on other measuring displays or setting display excluding the initial display, it will be moved to the initial display automatically.

Display	Button	Contents
<p>1000 A R S T N 100% 50%</p>		<p>The %load is indicated based on I_r current. Example) When I_r Knob is set on 0.4 at 2000AF, 100% I_r means 800A (0.4*2000).</p>
<p><u>Metering Overview</u> VR 220 V ∠ 0.0 IR 1000 A ∠ 330.0 P 986 kW Q 569 kVar Pf 0.866 F 60.0 EP 56 kWh EQ 32 kVarh</p>		<ol style="list-style-type: none"> 1. P : 3 phase active power 2. Q : 3 phase reactive power 3. Pf : Synthesis power factor 4. EP : Forward Energy Display 5. EQ : Energy consumption Display
<p><u>Demand Current[A]</u> R : 1000 S : 1000 T : 1000 <u>Max Demand [kW]</u> 986 2012/05/14 11:15:00</p>		<ol style="list-style-type: none"> 1. Demand Current[A] 2. Max Demand Value & Occurring time information
<p><u>Max Power [kW]</u> 987 2012/05/14 10:00:00</p>		<ol style="list-style-type: none"> 1. Max power value & Occurring time information 2. Ground Current Occurring time information


E. P/S Type Measurement Display

4. Power Diagram Display

CAUTION

- Displaying the 3 phases voltage/current vector & symmetrical element analyzed value
- Please refer to the algorithm of measuring function.
- All values are updated once a second.
- As the decimal place is not calculated down, the sum of each phase could be slightly different from the total value.
- The scale control on display is automatic.



Energy Measurement Display



5. Energy Measurement Display

CAUTION

- Displaying each phase or synthetic energy measured
- Please refer to the algorithm of measuring function
- All values are updated once a second.
- The energy accumulation of each phase could be different from synthetic energy. (Reference 1).



It is not common, but when the phase power is like the diagram, the synthetic power is 200.

In case of R phase, the forward energy is accumulated by 100.

In case of S phase, the reverse energy is accumulated by 200.

In case of T phase, the forward energy is accumulated by 200.

The synthetic power energy is 200 so the forward energy is accumulated by 200.

After 1 hour under the condition,

[Forward active energy is.....]

R : 100 , S : 0 , T : 200 Total: 200

[Reverse active energy is.....]

R : 0 , S : 100 , T : 0 Total: 0

So, there will be difference among them.

E. P/S Type Measurement Display


6. Waveform and Harmonics Analysis Display



CAUTION


- Analyzes harmonics after obtaining the waveform of 3 phase voltage/current from 128 samples /cycle.
- Function of S type only.
- Refer to algorithm of the measurement function part.
- Displays TDD and K-factor value from current harmonics analysis.
- Executes once every 30 sec.
- Measures harmonics up to the 63rd.

Waveform and Harmonics Analysis



F. P/S Type Device Setting

1. Menu Arrangement





F. P/S Type Device Setting

2. Device H/W Setting - Wiring Setting


CAUTION

- P and S type support 3-phase 4-wire and 3-phase 3-wire type.
- According to wiring type, input the wiring method of voltage module correctly
- H/W Setting - set an accurate wiring method at the wiring setting.
- In case of 3-wire connection, connect N phase of VDM to FG



3P4W Voltage Wiring

3P3W Voltage Wiring




F. P/S Type Device Setting

3. Device H/W Setting - Communication Setting

CAUTION

- P and S type support MODBUS RS-485 communication
- It forms Multi-Drop method on RS-485 line
- Put in 150ohm as terminating resistance.




F. P/S Type Device Setting

4. Device H/W Setting - Password Setting

CAUTION

■ P and S type provide a password function to protect the device.
 Default password is '0000'. Users can change the password through password setting.




F. P/S Type Device Setting

5. Device H/W Setting - Time Setting

CAUTION

■ P and S type contain a precise timer (RTC) inside. User can adjust the time at a remote place or at the device.




F. P/S Type Device Setting

6. Device H/W Setting – PT Ratio Setting

CAUTION

■ P and S Type provide a PT ratio function to display accurate PT voltages
In case of using VDM, users can setting PT ratio.



F. P/S Type Device Setting


7. Device H/W Setting- Demand Setting



CAUTION

■ P and S type provide Demand measurement function. Demand cycle can be set by divisors of 60 minutes.

Measurement display



Setting



1.H/W Set
2.Relay Set
3.Events
4.Sys Info
5.L/R (L)

Password Input



1.Wiring
2.Comm
3.Password
4.Time-RTC
5.PT Ratio



6.Demand
7.Data Rst
8.DO Setup
9.Language



DEMAND
[60/30/20/15/10/
6/5/4/3/2/1] Minute
15



DEMAND
[60/30/20/15/10/
6/5/4/3/2/1] Minute
20

SETTING
CHANGE ?
Enter-YES
Esc-NO



Upper level menu after saving data



Upper level menu without saving

6.Demand
7.Data Rst
8.DO Setup
9.Language




F. P/S Type Device Setting

8. Device H/W Setting - Data Reset

CAUTION

■ P and S type continuously save maximum power, maximum demand, energy, the breaking numbers of a circuit breaker, and operating time of a circuit breaker. User can set the data as default and restart it.

Measurement display



Setting

M

- 1.H/W Set
- 2.Relay Set
- 3.Events
- 4.Sys Info
- 5.L/R (L)

Password Input

←

- 1.Wiring
- 2.Comm
- 3.Password
- 4.Time-RTC
- 5.PT Ratio



←

- 6.Demand
- 7.Data Rst
- 8.DO Setup
- 9.Language

←

- INITIALIZE
- Max Power
- Demand
- Energy
- CB Count

△

Reset ESC

←

DATA CLEAR ?

Enter-YES
Esc-NO

← Upper level menu after saving data
Reset ESC Upper level menu without saving

- 6.Demand
- 7.Data Rst
- 8.DO Setup
- 9.Language


F. P/S Type Device Setting

9. Device H/W Setting - DO Setting

CAUTION

■ P and S type have 3 Relay Outputs. User can set those upon their purposes such as relay operation, OCR/OCGR operating alarm, and overload alarm, etc.

Measurement display



Setting

M

- 1.H/W Set
- 2.Relay Set
- 3.Events
- 4.Sys Info
- 5.L/R (L)

Password Input

←

- 1.Wiring
- 2.Comm
- 3.Password
- 4.Time-RTC
- 5.PT Ratio



- 6.Demand
- 7.Data Rst
- 8.DO Setup
- 9.Language

←

	O	V	I	R	O	O	U
DO1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
LTD							
DO2	<input type="checkbox"/>					<input type="checkbox"/>	
AL							
DO3	<input type="checkbox"/>						
ALL							
MTD	<input type="checkbox"/>						

↻

	O	V	I	R	O	O	U
DO1	<input type="checkbox"/>						
LTD							
DO2	<input type="checkbox"/>					<input type="checkbox"/>	
AL							
DO3	<input type="checkbox"/>						
ALL							
MTD	<input type="checkbox"/>						

When LTD (Long-time delay trip) occurs, it closes DO1 Relay.

When Alarm (Overload) occurs, it closes DO2 Relay.

When any of LTD,S,I,G occurs, it closes DO3 Relay

When over frequency relay is activated, it operates DO2.

When voltage unbalance relay (VUN) is activated, it operates DO1.


CAUTION

■ Settings for DO operation are as follows:
→ LTD → S,I → GND → PTA → AL → ALL

F. P/S Type Device Setting

9. Device H/W Setting - DO Setting

---	DO does not operate at all events.
LTD	When long-time delay trip occurs, it closes the corresponding DO (Relay).
S,I	When short-time, instantaneous trip occurs, it closes the corresponding DO (Relay).
GND	When ground gault trip occurs, it closes the corresponding DO (Relay).
PTA	When Pre-Trip Alram trip occurs, it closes the corresponding DO (Relay).
AL	When overload (above 95% of the rated current) occurs, it closes the corresponding DO (Relay).
ALL	When any of LTD,S,I,GND trip occurs, it closes the corresponding DO (Relay).




F. P/S Type Device Setting

10. Device H/W Setting – Language Setting


CAUTION

■ P and S type can setting languages between English and Russian.



Measurement display



Setting



Password Input



F. P/S Type Device Setting

11. Event Information Display

Event information


- P and S type record up to 256 information of the events that took place in the device in accordance with time. In case where more than 256 events occurs, past events get deleted and new data gets recorded.
- Events that get recorded are as follows.

Change of device setting	Wiring method change	Records event when user changes wiring method
	Comm. config. Change	Records Comm. config. (Speed, Address, Swap) change
	Password change	Records info when password changes
	Time change	Records internal time info when it changes
	Demand setting change	Records when demand setting (demand cycle) changes
	DO setting change	Records when setting of DO1~DO3 changes
	OCR fine adjustment	Records when performing the fine adjustment for long-time delay, short-time delay, instantaneous relay setting of OCR
	OCGR fine adjustment	Records when performing fine adjustment of OCGR's relay current
	OVR/UVR change	Records when setting of OVR/UVR changes
	Unbalance relay setting change	Records when setting of voltage/current unbalance relay changes
	Reverse power relay setting change	Records when setting of reverse power changes
	Frequency relay setting change	Records when setting of Low/high frequency relay changes
Device error	OCR knob change	Records when changing long, short-time, instantaneous knob on the front side of device
	OCGR knob change	Records when changing the knob relating ground fault on the front side of device
	Internal comm. error	Records when comm. error occurs among internal CPUs
Device state change	MTD wiring fall out/cut off	Records when MTD (Magnetic Trip Device) wiring is wrongly connected
	Memory error	Records when internal memory error occurs
	Local / Remote change	Records when device mode changes Local→Remote, Remote→Local
	Power On	Records after initial booting when power of P/S type turns on
	Fault Reset	Records when fault occurs and reset is reset
	DO1 control (Close/Open)	Records when DO1's output changes OFF→ON, ON→OFF
Device info Change	DO2 control (Close/Open)	Records when DO2's output changes OFF→ON, ON→OFF
	DO3 control (Close/Open)	Records when DO3's output changes OFF→ON, ON→OFF
	Max. power reset	Records when max. power resets
	Max. demand reset	Records when max. demand resets
	Energy reset	Records when energy (electric) resets
	Event info reset	Records when deleting all event info
	Fault info reset	Records when deleting all Fault info


F. P/S Type Device Setting

11. Event Information Display


Measurement display



Setting





Password input



10 events recorded at present time

Changing information locally

The earliest event took place on 2012/03/14 at 10:11:24, when the user changed comm. info.



The latest event took place on 2012/03/14 at 20:29:41, when P/S type were powered and booted.

F. P/S Type Device Setting

11. Event Information Display


Display		
Device configuration change → “Cfg Change”	Wiring method change	“Wiring”
	Comm. config. change	“Comm Setup”
	Password change	“Password”
	Time change	“Time Change”
	Demand setting change	“Demand”
	DO setting change	“OCR DO Config”
	OCR fine adjustment	“OCR Fine Set”
	OCGR fine adjustment	“OCGR Fine Set”
	OVR/UVR change	“OVR/UVR”
	Unbalance relay setting change	“Unbal RY”
	Reverse/Over power relay setting change	“rP/OPR RY”
	Frequency relay setting change	“OFR/UFR”
	OCR knob change	“OCR Knob”
	OCGR knob change	“OCGR Knob”
Device error → “Error”	Internal communication error	“Inter Comm”
	MTD wiring fall out/cut off	“MDT Wire”
	Memory error	“Memory”
Device state change → “Sta Change”	Local / Remote change	“Local 2 Remote” “Remote 2 Local”
	Power on	“Power On”
	Fault Reset	“Trip Reset”
	DO1 control (Close/Open)	“DO#1 CTRL”
	DO2 control (Close/Open)	“DO#2 CTRL”
	DO3 control (Close/Open)	“DO#3 CTRL”
Device info change → “Rst Data”	Max. power reset	“Reset MaxP”
	Max. demand reset	“Reset Demand”
	Energy reset	“Reset Energy”
	Event info clear	“Clear Sys Event”
	Fault info clear	“Clear Trip Event”

- P and S type record the faults occurred from device (Trip & selective relay operation) up to 256 to know operation info and factor when trip or relay operates.
- Past data gets deleted and new data gets recorded when records exceeds 256.
- The contents of record are as follows.

Fault Information	Long-time	Records when Over Current Relay operates
	Short-time	Records when Short-time delay trip operates
OCR OCGR	Instantaneous	Records when Instantaneous trip operates
	Ground fault	Records when Ground fault trip occurs
	Ground fault -ZCT	Records when Ground fault(external CT) trip occurs
	Leakage	Records when trip occurred due to Leakage current
	PTA (Pre Trip Alarm)	Records when Pre Trip Alarm Relay operates
Selective Relay	OVR	Records when OVR Relay operates
	UVR	Records when UVR Relay operates
	Voltage Unbalance	Records when Voltage Unbalance Relay operates
	Current Unbalance	Records when Current Unbalance Relay operates
	Over Power	Records when Current Unbalance Relay operates
	Reverse Power	Records when Over Power Relay operates
	OFR	Records when Over Frequency Relay operates
	UFR	Records when Under Frequency Relay operates

F. P/S Type Device Setting

12. Fault Information Display



F. P/S Type Device Setting

12. Fault Information Display

Display – Fault Information

OCR OCGR	Long-Time Delay	“OCR-Long”
	Short-Time Delay	“OCR-Short”
	Instantaneous	“OCR-Ins”
	Ground fault	“OCGR”
	Ground fault -CT(External-CT)	“OCGR-ZCT”
	Leakage	“Leakage”
Selective Relay	PTA (Pre Trip Alarm)	“PTA”
	OVR	“OVR”
	UVR	“UVR”
	Voltage Unbalance	“Vunbal”
	Current Unbalance	“Iunbal”
	Reverse Power	“rP”
	Over Power	“OPR”
	OFR	“OFR”
	UFR	“UFR”

Display – Indication of fault phase and trip value

OCR OCGR	Long-Time Delay	“Phase-R xxx A” “Phase-S xxx A” “Phase-T xxx A” “Phase-N xxx A”
	Shot-Time Delay	
	Instantaneous	
	IDMTL	
	Ground fault	“xxx A”
	Leakage	“xxx A”
Selective Relay	PTA (Pre Trip Alarm)	“xxx A”
	OVR	“Phase-R xxx V”
	UVR	“Phase-S xxx V” “Phase-T xxx V”
	Voltage Unbalance	“xx %”
	Current Unbalance	“xx %”
	Reverse Power	“xxx kW”
	Over Power	“xxx kW”
	OFR	“xx Hz”
	UFR	“xx Hz”


F. P/S Type Device Setting

13. Event Information / Fault Information Deletion


CAUTION

- P and S type can record up to 256 event info and 256 fault info.
- User can delete the corresponding event or fault list at the user's discretion .
- Deleted info remains in the event info



Measurement display




Setting



Password input



- ← Event list reset
- Reset ESC Upper level menu without data reset



F. P/S Type Device Setting


14. System Information Display

CAUTION


- P and S type can indicate its own information including the information of the ACB
- 1) Present time
 - 2) ACB current ratings
 - 3) N-phase current ratings (50%, 100%)
 - 4) Frequency information (60Hz, 50Hz)
 - 5) Breaking / Closing numbers of a circuit breaker (nr. of operating times)
 - 6) OCR operating time
 - 7) Conducting time of a circuit breaker
 - 8) F/W version info

System Information

Measurement display



Setting



Password input

System Info.

Date Time
2012/05/15 21:23:30

Rating	1000 A
Ex-Func	4POCGR
Freq	60 Hz
CB ON#	23
Ver-Arm	1.50

System Info.

Date Time
2012/05/15 21:23:30

Rating	1000 A
Ex-Func	4POCGR
T-OPER	220 h
T-CB ON	180 h
Ver-Msp	4.01A

Rating	Rated current of ACB
N-Phase	Standard ratio of phase conductor for N phase conductor of ACB
Freq	Rated frequency
CB ON#	Breaking/Closing numbers of a circuit breaker
T-OPER	OCR(P/S type) operating time
T-CB ON	Operating time of ACB under closed condition
Version	Firmware version


F. P/S Type Device Setting

15. Local / Remote Setting


CAUTION

- For P and S type, one can set whether to control locally or remotely. .
- When device is set to local, every operation is available through the Key of OCR..
- When device is set to Remote, it is locked not to be controlled from the local site.




Measurement display





Setting



Password input



-  Upper level menu after saving data
-  Upper level menu without saving data

Leader in Electrics & Automation

LSIS Co., Ltd.

■ HEAD OFFICE

LS Tower, LS-ro 127, Dongan-gu, Anyang-si,
Gyeonggi-Do, 14119, Korea
<http://eng.lsis.com>

■ CHEONG-JU PLANT

Cheong-Ju Plant #1, Song Jung Dong, Hung Duk Ku,
Cheong Ju, 361-720, Korea

■ Global Network

• LSIS (Middle East) FZE >> Dubai, U.A.E.

Address: LOB 19, JAFZA VIEW TOWER Room 205,
Jebel Ali Freezone P.O. Box 114216, Dubai, United Arab Emirates
Tel: 971-4-886-5360 Fax: 971-4-886-5361 e-mail: jungyong@lsis.biz

• Dalian LSIS Co., Ltd. >> Dalian, China

Address: No. 15, Liaohai 3-Road, Economic and Technical
Development zone, Dalian 116600, China
Tel: 86-411-8273-7777 Fax: 86-411-8730-7560 e-mail: ldx@lsis.com.cn

• LSIS (Wuxi) Co., Ltd. >> Wuxi, China

Address: 102-A, National High & New Tech Industrial Development Area,
Wuxi, Jiangsu, 214028, P.R.China
Tel: 86-510-8534-8888 Fax: 86-510-522-4076 e-mail: xuhp@lsis.com.cn

• LSIS-VINA Co., Ltd. >> Hanoi, Vietnam

Address: Nguyen Kha - Dong Anh - Ha Noi - Viet Nam
Tel: 84-4-862-0222 Fax: 84-4-862-0220 e-mail: arjo@lsisvina.biz

• LSIS-VINA Co., Ltd. >> Hochiminh, Vietnam

Address: 41 Nguyen Thi Minh Khai St, Yoco Bldg 4th Floor,
Hochiminh City, Vietnam
Tel: 84-8-3822-7941 Fax: 84-8-3822-7942 e-mail: sbperk@lsisvina.biz

• LSIS Shanghai Office >> Shanghai, China

Address: Room 5-G, 12th Floor Huamin Empire Plaza, No 728,
West Yan'an Road Shanghai 200050, P.R. China
Tel: 86-21-5237-9977 (609) Fax: 86-21-5237-7191 e-mail: jinhk@lsis.com.cn

• LSIS Beijing Office >> Beijing, China

Address: B-Tower 17FL, Beijing Global Trade Center B/D, No 36,
Beisanhuan Dong-Lu, Dongcheng-District, Beijing 100013, P.R. China
Tel: 86-10-5825-6025,7 Fax: 86-10-5825-6026 e-mail: oukiao@lsis.com.cn

• LSIS Guangzhou Office >> Guangzhou, China

Address: Room 1403-14F, New Poly Tower, 2 Zhongshan Liu Road,
Guangzhou, P.R.China
Tel: 86-20-8328-6764 Fax: 86-20-8328-6287 e-mail: lnsa@lsis.biz

• LSIS Cheongdu Office >> Cheongdu, China

Address: Room 1701 17Floor, Huameninhanjun International Building,
No1 Fuxing Road Cheongdu, 610041, P.R.China
Tel: 86-28-8670-3101 Fax: 86-28-8670-3203 e-mail: yangz@lsis.com.cn

• LSIS Qingdao Office >> Qingdao, China

Address: 7B40, Habin Guangchang Shenyu Building B, No.8,
Shandong Road Qingdao 26600, P.R. China
Tel: 86-532-8501-8888 Fax: 86-532-883-3793 e-mail: lrj@lsis.com.cn

• LSIS NETHERLANDS Co.Ltd >> Netherlands

Address: 1st Floor, Tusschevaan 45, 1119AZ, Schiphol-Rijk, The Netherlands
Tel: 31-20-694-1420 Fax: 31-20-694-1429 e-mail: junschick@lsis.biz

• LSIS Gurgaon Office >> Gurgaon, India

Address: 109 First Floor, Park Central, Sector-30, Gurgaon-122002,
Haryana, India



Technical Question or After-Sales Service

Customer Center - Quick Responsive Service, Excellent technical support

TEL. **82-1644-5481** | Home page: <http://www.lsis.com>

Vacuum Circuit Breaker
2011, 9

Specifications in this instruction manual are subject to change without notice due to continuous products development and improvement.

79563460002

Instruction Manual for Susol & Metasol ACB 2008.06/2008.06 JUNG-AMG