



Step 1: Loosen all cover screws.



Step 2: Remove keypad connector.





Step 3: Remove the keypad adapter PCB. It may be helpful to use a screwdriver to clear the plastic tabs.



Step 4: Once the keypad PCB adapter is removed, install the two standoffs which are included in the Ethernet card kit.





Step 5: Install the Ethernet card.



Step 6: Install the two screws to secure the Ethernet card to the standoffs. Snap the keypad adapter PCB into place on top of the Ethernet card.





Step 7: Reconnect keypad connector cable. Connect network cable. Re-install front cover.